

### Instructions For Use

## FLS-1-IFU

Rev. Date: Dec. 7, 2018

**Revision: 4** 

Page 1 of 3

P.O. Box 3286 - Logan, Utah 84323, U.S.A. - Tel. (800) 729-8350 - Tel. (435) 755-9848 - Fax (435) 755-0015 - www.scytek.com

## Fite's Stain Kit

(For Leprosy and Nocardia)

**Description:** The Fite's Stain Kit (For Leprosy and Nocardia) is intended for use in the histological visualization of

mycobacterium Lepra bacillus and Nocardia. This kit may be used on formalin-fixed, paraffin-embedded

sections.

Lepra bacillus: Red Nocardia: Red Background: Blue

**Uses/Limitations:** Not to be taken internally.

For In-Vitro Diagnostic use only.

Histological applications.

Do not use if reagents become cloudy. Do not use past expiration date. Use caution when handling reagents.


Non-Sterile.

Control Tissue: TCS0009-5 (5 Slides)

TCS0009-25 (25 Slides)

Any well fixed paraffin embedded Nocardia or Lepra bacillus infected

tissue.



## Ordering information regarding individual components on back page!

#### **Kit Contents:**

Kit Contents	<u>Volume</u>	<u>Storage</u>
Xylene-Peanut Oil Solution	125 ml	18-25°C
Carbol Fuchsin Solution	125 ml	18-25°C
Acid Alcohol Solution (1%)	500 ml	18-25°C
Methylene Blue Solution	125 ml	18-25°C
	Carbol Fuchsin Solution Acid Alcohol Solution (1%)	Xylene-Peanut Oil Solution 125 ml Carbol Fuchsin Solution 125 ml Acid Alcohol Solution (1%) 500 ml

**Precautions:** Avoid contact with skin and eyes.

Harmful if swallowed.

Follow all Federal, State, and local regulations regarding disposal.

Storage: 18° C 25° C





Prinsessegracht 20 2514 AP The Hague, The Netherlands



# Instructions For Use FLS-1-IFU

Rev. Date: Dec. 7, 2018

**Revision: 4** 

Page 2 of 3

P.O. Box 3286 - Logan, Utah 84323, U.S.A. - Tel. (800) 729-8350 - Tel. (435) 755-9848 - Fax (435) 755-0015 - www.scytek.com

#### Lepra bacillus Procedure (Standard):

- 1. Deparaffinize sections in 2 changes of Xylene-Peanut Oil Solution for 12 minutes each.
- 2. Air dry slide for 15 minutes "without" removing oil film covering tissue section. Remaining film prevents de-staining of Lepra bacillus during differentiation.
- 3. Rinse slide in several changes of distilled water.
- 4. Incubate slide in Carbol Fuchsin Solution for 15 minutes.
- 5. Rinse slide in several changes of distilled water.
- 6. Differentiate section in Acid Alcohol Solution (1%) until background is pink.
- 7. Rinse slide in distilled water and check by microscope for correct differentiation.
- 8. Rinse in running tap water for 1 minute followed by 1 rinse in distilled water.
- 9. Dip slide 2-3 times in Methylene Blue Solution.
- 10. Dip slide quickly in distilled water and check by microscope for correct staining.
- 11. Air dry slide at room temperature.
- 12. Dip slide several times in Xylene or Xylene Substitute.
- 13. Mount in synthetic resin.

#### **Nocardia Procedure:**

#### **Preparation of Reagents Prior to Beginning:**

1. Prepare **Diluted Acid Alcohol Solution** by mixing 25ml of Acid Alcohol Solution (1%) with 25ml of Distilled Water.

#### **Procedure:**

- 1. Deparaffinize sections in 2 changes of Xylene-Peanut Oil Solution for 12 minutes each.
- 2. Air dry slide for 15 minutes "without" removing oil film covering tissue section. Remaining film prevents de-staining of Lepra bacillus during differentiation.
- Rinse slide in several changes of distilled water.
- 4. Incubate slide in Carbol Fuchsin Solution for 15 minutes.
- 5. Rinse slide in several changes of distilled water.
- 6. Dip slide 2-3 times in Diluted Acid Alcohol Solution.
- Rinse slide in distilled water and check by microscope for correct differentiation. Avoid decolorizing the Nocardia organism.
- 8. Rinse in running tap water for 1 minute followed by 1 rinse in distilled water.
- 9. Dip slide 2-3 times in Methylene Blue Solution.
- 10. Dip slide quickly in distilled water and check by microscope for correct staining.
- 11. Air dry slide at room temperature.
- 12. Dip slide several times in Xylene or Xylene Substitute.
- 13. Mount in synthetic resin.

Storage: 18° C 25° C

ScyTek Laboratories, Inc. 205 South 600 West Logan, UT 84321 U.S.A.

CE

IVD

Emergo Europe
Prinsessegracht 20
2514 AP The Hague, The Netherlands



## Instructions For Use FLS-1-IFU

Rev. Date: Dec. 7, 2018

**Revision: 4** 

Page 3 of 3

P.O. Box 3286 - Logan, Utah 84323, U.S.A. - Tel. (800) 729-8350 - Tel. (435) 755-9848 - Fax (435) 755-0015 - www.scytek.com

#### References:

- 1. Echeverri, C., et al. Fite Stain Positivity in Rhodococcus equi: Yet Another Acid-Fast Organism in Respiratory Cytology – A Case Report. Diagnostic Cytopathology; April 2001, Volume 24, Issue 4, pages 244-246.
- Crowder, C., Taylor, HW., Modified Fite Stain for Demonstration of Mycobacterium Species in Tissue Sections; Journal of 2. Histotechnology; 1996, Volume 19; 2: pages 133-134.
- Mallory, Pathological Technique; page 275. 3.

#### Bulk Reagent Ordering Information and Current Pricing at www.scytek.com

Description:	Catalog #	Volume
Xylene-Peanut Oil Solution	XPO125 XPO500 XPO999	125 ml 500 ml 1000 ml
Carbol Fuchsin Solution	CFZ125 CFZ500 CFZ999	125 ml 500 ml 1000 ml
Acid Alcohol Solution (1%)	AAM500 AAM999	500 ml 1000 ml
Methylene Blue Solution	MBS125 MBS500 MBS999	125 ml 500 ml 1000 ml

